

P80

Rugged Tablets

Accessories Guide



STD. Spec.

Adapter



PWR-P80-5V2A-CN



PWR-P80-5V2A-EU



PWR-P80-5V2A-UK



PWR-P80-5V2A-US

Adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 5V2A, use with DC-BK-TypeC cable

USB cable



DC-BK-TypeC
1.0 meter Type-C cable

Sim tray ejector



SIM-TRAY-EJECTOR
SIM tray ejector

Hand Strap



SG-P80-HDSTP
Hand Strap

Optional

Rugged Rubber Boot



RB-P80-RR
Rugged Rubber Boot, omni-directional protected, can be installed with standard VESA holder with interface- FDMI MIS-C, and vehicle-mounted bracket MOT-P80 that need to be purchased separately.

Holder



MOT-P80
Holder, 110*50*40*1.5

Pistol grip



TRG-P80-PG
P80 Pistol grip, read UHF tag and barcode scanning like pressing the trigger.

Charging Cradles & Adapters



CRD-P80-RBC
Charging Cradle for device, use with DCPWR-12V2A-XX adapter. The cradle cup has an insert that is fixed by 4 pcs screws and they must be removed in prior when charging P80 with rugged boot.



CRD-P80-INS
Insert for P80 cradle cup. 4 pcs M2*6.0 screws are necessary.



DCPWR-12V2A-XX
Adapter(CN/EU/UK/US/IND), I/P: 100-240V, O/P: 12V2A, DC

